



**DEPARTURE ROUTE DESCRIPTION**

**TAKE-OFF RWY 07:**  
Turn left via 270° to intercept the airway assigned by ATC.  
Turn right via 180° to intercept the airway assigned by ATC.

**TAKE-OFF RWY 25:**  
Turn right via 350° to intercept the airway assigned by ATC.  
Turn left via 100° to intercept the airway assigned by ATC.